



# Bio|MAX UCLA abutment



**Blue Sky Bio**

# Bio|MAX UCLA abutment

Assemble screw driver with  
Thumb Knob




Remove healing abutment  
from implant




Blue Sky Bio

# Bio|MAX UCLA abutment

Insert the Impression Transfer into the implant ensuring the appropriate orientation




Tighten the screw with the driver assembly with light finger force




Blue Sky Bio

# Bio|MAX UCLA abutment




Remove screwdriver  
assembly

Apply wax to the top of the  
Impression.



 Blue Sky Bio

# Bio|MAX UCLA abutment



Inject impression material around the impression




**Blue Sky Bio**

# Bio|MAX UCLA abutment



Insert tray with impression material




Seat impression to capture dental arch



**Blue Sky Bio**

# Bio|MAX UCLA abutment



Remove the impression from the mouth when material has set




**Blue Sky Bio**


# Bio|MAX UCLA abutment



Use a sharp instrument to remove the wax from the impression transfer




Remove impression transfer from implant




Blue Sky Bio

# Bio|MAX UCLA abutment



Healing abutment in place


# Bio|MAX UCLA abutment




Blue Sky Bio

# Bio|MAX UCLA abutment

Align the flats of UCLA Abutment with the flats within the impression and insert the abutment/analog assembly into the impression



UCLA Abutment/analog assembly completely seated inside impression



Blue Sky Bio

# Bio|MAX UCLA abutment

Apply soft tissue replica material around implant level analog




Pour dental stone into impression



**Blue Sky Bio**

# Bio|MAX UCLA abutment


Remove model from impression and loosen the fixation screw of the impression transfer by turning screw driver counter clockwise



Insert the UCLA abutment into the implant level analog ensuring the appropriate orientation. Hand tighten the fixation screw within the UCLA abutment



Insert screw driver assembly into fixation screw in the UCLA abutment




Blue Sky Bio

# Bio|MAX UCLA abutment

Create a wax up of the desired shape of the abutment by subtracting or adding to the resin of the UCLA abutment




Cast and finish custom UCLA abutment



**Blue Sky Bio**

# Bio|MAX UCLA abutment

Seal the screw opening of the  
UCLA Abutment



Apply die spacer and wax up  
undercasting on the UCLA Abutment




**Blue Sky Bio**

# Bio|MAX UCLA abutment

Cast wax up using a conventional technique and insert it in the casting on the stone model



Stack and fire the Ceramic in the usual manner




Porcelain crown on model



Blue Sky Bio

# Bio|MAX UCLA abutment



Insert the abutment into implant  
orienting it according to the  
instructions from the laboratory and  
tighten with driver




**Blue Sky Bio**

# Bio|MAX UCLA abutment

Insert the hex driver into the 30Ncm torque ratchet



Insert driver into the abutment screw tighten the screw until torque of 30 Ncm is reached and the head of the ratchet releases



Blue Sky Bio

# Bio|MAX UCLA abutment



Cement restoration on abutment



**Blue Sky Bio**